

MAGNUM A SERIES DIESEL SOD INSTALLER PARTS MANUAL



**MAGNUM A42D
MAGNUM A48D**

Bucyrus Equipment Co., Inc.
Box 156, 209 Main
Hillsdale, Ks 66036
1-800-330-0857
www.magnumenp.com

RE-ORDER NUMBER: 2IND-MANUAL
REVISION: 2IND-100010



A SERIES

MAGNUM A42D / A48D PARTS MANUAL

The purpose of this manual is for parts identification of the Magnum A series sod installer. This manual is not to be used for assembly. This manual includes parts lists and illustrations of all available replacement parts for the Magnum A series sod installer. A table of contents is placed at the beginning of the manual for location of specific parts. Keep this manual available for reference in the shop area.

At the time of publication all information contained in this manual was technically correct. However, all materials and specifications are subject to change without notice.

Comments and suggestions about this manual may be directed to: Bucyrus Equipment Co., Inc., PO Box 156-209 Main, Hillsdale, KS 66036. Phone 1-800-330-0857

© Copyright 2013 BECI. All information contained within this publication is based on the latest product information at the time of publication. Due to constant improvements in the design and quality of production components, some minor discrepancies may result between the actual vehicle and the information presented in this publication. Depictions and/or procedures in this publication are intended for reference use only. No liability can be accepted for omissions or inaccuracies. Any reprinting or reuse of the depictions and/or procedures contained within, whether whole or in part, is expressly prohibited. Printed in U.S.A.

RE-ORDER NUMBER: 2IND-MANUAL
REVISION: 2IND-100010

TABLE OF CONTENTS

Section 1	BRAKE, WHEEL, & HUB
Section 2	DECALS
Section 3	ELECTRICAL
Section 4	ENGINE
Section 5	FRONT SPENDLE
Section 6	HYDRALICS
Section 7	HYDROSTAT ROLL LIFT CONTROL
Section 8	OPERATORS PLATFORM
Section 9	ROLL LIFT
Section 10	SHIELDS
Section 11	STEERING AXLE

ROLL LIFT - Parts List


ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	2IND-RL200	ROLL LIFT PIN LOCKING TAB
2	2	2IND-RL102	ROLL LIFT PIVOT PIN
3	4	020DXR012	1 1/4 X 3/4 METAL/POLYMER BEARING
4	4	60105	1/4"-28 GREASE FITTING, ST
5	4	97669A400	3/4"-10 GA SHIM
6	2	0156790	3/4" X 3 1/2" CLEVIS PIN
7	8	65078	1/8" X 1-1/2" COTTER PIN
8	1	2IND-RL100	ROLL LIFT
9	4	64UBOLT	U BOLT
10	2	IN-RL103	CLAMP
11	2	IN-RL104	CLAMP STINGER
12	2	IN-RL105	PLATE, ROLL LIFT CLAMP CONE (OPTION)
13	2	IN-RL102	CLAMP PIVOT PIN
14	1	48IN-RL101	CLAMP ARM BAR, 48"
15	1	IN-RL107	CLAMP ARM BAR, 42"
16	8	33897	5/8" LOCK WASHER
17	1	2IND-RL101R	CLAMP ARM, RIGHT
18	2	IN-RL106	CLAMP ARM BAR MOUNT
19	1	48IN-RL200	ROLL LIFT SOLID ARM BAR, 48
20	1	IN-RL202	SOLID ARM BAR, 42"
21	1	2IND-RL103R	SOLID ARM, RIGHT
22	1	2IND-RL103L	SOLID ARM, LEFT
23	2	1D155	1" X 3" CLEVIS PIN
24	2	33820	3/4" SAE WASHER
25	4	100075075	STEEL SPRING BUSHING
26	2	100075100	STEEL SPRING BUSHING
27	2	65127	3/16" COTTER PIN
28	2	SC219-2	3/4" CLEVIS PIN, GREASABLE
29	2	60107	1/4"-28 GREASE FITTING, 90
30	8	33893	3/8" LOCK WASHER
31	2	33007	3/8 FLAT WASHES
32	4	13107	3/8"-16 X 1 1/4" CAPSCREW
33	6	13105	3/8"-16 X 1" CAPSCREW
34	8	020DXR016	1 1/4 X 1 METAL/POLYMER BEARING
35	4	13207	1/2"-13 X 1 1/4" CAPSCREW
36	4	33861	1/2" FLAT WASHER
37	4	33895	1/2" LOCK WASHER
38	2	0156783	5/8" X 3" CLEVIS PIN





ROLL LIFT


ITEM	QTY	PART NUMBER	DESCRIPTION
39	8	36314	5/8"-11 HEX NUT
40	2	0156788	3/4" X 2 3/4" CLEVIS PIN
41	2	662642	3 X 6 X 1 3/8 HYDAULIC CYLINDER
42	1	2IND-RL101L	CLAMP ARM, LEFT
43	2	IN-RL300	CLAMP CYLINDER
44	1	48IN-RL103R	CLAMP ARM SPACER BLOCK MNT, RHS
45	2	48IN-RL102	CLAMP SPACER BLACK
46	1	48IN-RL103L	CLAMP ARM SPACER BLACK MNT, LHS
47	2	13109	3/8" – 16 X 1 1/2" CAPSCREW
48	4	36306	3/8" – 16 HEX NUTS
49	8	33859	3/8" FLAT WASHER
50	4	33860	7/16" FLAT WASHER
51	4	12219	1/2" – 13 X 4" CAPSCREW

















[illegible]