# MAGNUM M SERIES DIESEL SOD INSTALLER

## PARTS MANUAL

## MAGNUM M4226D
## MAGNUM M4826D

**Bucyrus Equipment Co., Inc.**
**Box 156, 209 Main**
**Hillsdale, Ks 66036**
**1-800-330-0857**
**www.magnumenp.com**

RE-ORDER NUMBER: IND-MANUAL
REVISION: IN-100007

RE-ORDER NUMBER:  IND-MANUAL
REVISION: IN-100007

# M SERIES

# MAGNUM M4226D / M4826D
# PARTS MANUAL

The purpose of this manual is for parts identification of the Magnum M series sod installer. This manual is not to be used for assembly. This manual includes parts lists and illustrations of all available replacement parts for the Magnum M series sod installer. A table of contents is placed at the beginning of the manual for location of specific parts. Keep this manual available for reference in the shop area.

At the time of publication all information contained in this manual was technically correct. However, all materials and specifications are subject to change without notice.

Comments and suggestions about this manual may be directed to: Bucyrus Equipment Co., Inc., PO Box 156-209 Main, Hillsdale, KS 66036. Phone 1-800-330-0857

© Copyright 2013 BECI. All information contained within this publication is based on the latest product information at the time of publication. Due to constant improvements in the design and quality of production components, some minor discrepancies may result between the actual vehicle and the information presented in this publication. Depictions and/or procedures in this publication are intended for reference use only. No liability can be accepted for omissions or inaccuracies. Any reprinting or reuse of the depictions and/or procedures contained within, whether whole or in part, is expressly prohibited. Printed in U.S.A.

RE-ORDER NUMBER: IND-MANUAL
REVISION: IN-100007

# TABLE OF CONTENTS

**Section 1 ……. Brake / Wheel / Hub**

**Section 2 ……. Decals**

**Section 3 ……. Electrical**

**Section 4 ……. Engine**

**Section 5 ……. Front Spindle**

**Section 6 ……. Hydraulics**

**Section 7 ……. Hydrostat / Roll Lift Controls**

**Section 8 ……. Operator Platform**

**Section 9 ……. Roll Lift**

**Section 10 ……. Shields**

**Section 11 ……... Steering Axle**

## DECALS - PARTS LIST

| ITEM | QTY | PART NUMBER | DESCRIPTION |
|---|---|---|---|
| 1 | 1 | IN-DCL101 | FOWARD/REVERSE - ARMS RAISE/LOWER DECAL |
| 2 | 1 | IN-DCL102 | WHEELS INBOARD DECAL |
| 3 | 1 | IN-DCL103 | 2X DECAL |
| 4 | 1 | IN-DCL104 | 4X DECAL |
| 5 | 1 | IN-DCL105 | FLUID LEVEL DECAL |
| 6 | 1 | IN-DCL107 | SYNTHETIC HYDRAULIC FLUID ONLY DECAL |
| 7 | 1 | IN-DCL109 | SAFETY INSTRUCTIONS DECAL |
| 8 | 2 | IN-DCL110 | READ OPERATORS MANUAL DECAL |
| 9 | 1 | IN-DCL111 | WARNING PLATFORM DECAL |
| 10 | 2 | IN-DCL113 | LOCK DECAL |
| 11 | 2 | IN-DCL114 | UNLOCK DECAL |
| 12 | 1 | IN-DCL115 | WHEEL LOCK DECAL |
| 13 | 1 | IN-DCL116 | ALT / TEMP / OIL DECAL |
| 14 | 1 | IN-DCL117 | FUEL FILTER DECAL |
| 15 | 1 | IN-DCL118 | HYDRAULIC FILTER DECAL |
| 16 | 2 | IN-DCL120 | YELLOW MAGNUM DECAL |
| 17 | 1 | IN-DCL121 | LIGHTS DECAL *(WITH LIGHT KIT OPTION ONLY)* |
| 18 | 1 | IN-DCL122 | PARKING BRAKE DECAL |
| 19 | 1 | IN-DCL123 | KEEP GAURDS IN PLACE DECAL |
| 20 | 1 | IN-DCL124 | AIR FILTER DECAL |
| 21 | 1 | IN-DCL125 | FAN CUTTING FINGERS/HAND DECAL |
| 22 | 2 | IND-DCL100 | M4226D MODEL NUMBER DECAL |
| | 2 | 48IND-DCL100 | M4826D MODEL NUMBER DECAL (48” MODEL ONLY) |
| 23 | 1 | IND-DCL200 | ULTRA LOW SULFUR DIESEL DECAL |
| 24 | 1 | STKE | HYDRAULIC WARM UP DECAL |
| 25 | 1 | STKG | BUCYRUS EQUIPMENT CO., INC. DECAL |
| 26 | 2 | STKZ | MAGNUM STRIPE DECAL |


LOCK
WHEEL LOCK
NOTICE
UNLOCK
UNLOCK
LOCK
FUEL FILTER
HYDRAULIC FILTER
2 X
4 X
WHEELS INBOARD
PARKING BRAKE
10
12
11
14
15
2
18
3
4


8
19
9
WARNING
CAUTION
Read and understand operator manual before operating the machine.
WARNING
Avoid injury.
8
CAUTION
Read and understand operator manual before operating the machine.
WHEELS INBOARD
PARKING BRAKE
2 X
4 X


7
24
13
1
17
25
FORWARD
RAISE ARMS
LOWER ARMS
REVERSE
ALT TEMP OIL
BUCYRUS EQUIPMENT CO., INC.
HILLSDALE, KS 66036
913-783-4600


AIR
FILTER
20
21


23
USE
ULTRA-LOW
SULFUR DIESEL
FUEL ONLY
Magnum
M4226D
16
26
22


16
26
22
M426D
Magnum
CAUTION
DO NOT FILL
ABOVE LINE
6
5




IN-DCL101

IN-DCL102

IN-DCL103

IN-DCL104

IN-DCL105

IN-DCL107

IN-DCL109

IN-DCL110

IN-DCL111

IN-DCL113

IN-DCL114

IN-DCL115




IN-DCL116

IN-DCL117

IN-DCL118

IN-DCL121

IN-DCL122

IN-DCL123

IN-DCL124

IND-DCL200

STKE

STKG

IN-DCL125

IN-DCL120

STKZ

IND-DCL100




48IND-DCL100

NOTES: